


# StoTherm® ci

## Rough Opening Sill Preparation over Wood Frame

Detail No.: 2.22

Date: January 2015



### Notes:

- 1] Prepare rough opening as illustrated in Sto Detail 2.20.
- 2] Provide flashing as part of the sub-sill drainage assembly used in lieu of pan flashing.
- 3] Size width of flashing to drain water penetration through the window and the perimeter sealant joint.
- 4] Coordinate StoGuard installation sequence with window installer and other related trades.
- 5] Install window so that adequate space for drainage is maintained between nail fin and StoGuard.
- 6] The complete installation of window or mechanical equipment should include an air seal connection between the object and StoGuard Waterproofing/Air Barrier. Provide the air seal connection inbound of the outer perimeter sealant joint.
- 7] Additional transition membrane treatments are presented in Sto Detail Series 20.xx.
- 8] Refer to Sto specifications and product bulletins for detailed information on substrates and Sto material options.

IMPORTANT: Components not identified as Sto are furnished by other manufacturers and are not necessarily installed by trades who install the Sto products. Refer to project specific contract documents.

### Attention

Sto products are intended for use by qualified professional contractors, not consumers, as a component of a larger construction assembly as specified by a qualified design professional, general contractor or builder. They should be installed in accordance with those specifications and Sto's instructions. Sto Corp. disclaims all, and assumes no, liability for on-site inspections, for its products applied improperly, or by unqualified persons or entities, or as part of an improperly designed or constructed building, for the nonperformance of adjacent building components or assemblies, or for other construction activities beyond Sto's control. Improper use of Sto products or use as part of an improperly designed or constructed larger assembly or building may result in serious damage to Sto products, and to the structure of the building or its components. **STO CORP. DISCLAIMS ALL WARRANTIES EXPRESS OR IMPLIED EXCEPT FOR EXPLICIT LIMITED WRITTEN WARRANTIES ISSUED TO AND ACCEPTED BY BUILDING OWNERS IN ACCORDANCE WITH STO'S WARRANTY PROGRAMS WHICH ARE SUBJECT TO CHANGE FROM TIME TO TIME.** For the fullest, most current information on proper application, clean-up, mixing and other specifications and warranties, cautions and disclaimers, please refer to the Sto Corp. website, [www.stocorp.com](http://www.stocorp.com).

[www.stocorp.com](http://www.stocorp.com)